

Installation Instruction

for soft skirting board WL 50 life

(contains no chlorine or softeners)

1. Applications

The “WL 50 life” soft skirting board is used mainly on elastic and hard floor covering. Its high flexibility allows unevenness on walls and floors to be compensated.

2. Material properties

The “WL 50 life” profile consists of a polyolefin based polymer which

- contains no toxic substances
- contains no solvents, softeners, chlorine or other halogens and no heavy metals such as lead, cadmium or similar
- the material is completely iner

3. Storage and transport

- The “WL 50 life” soft skirting boards should lie rolled up in their packaging, with a cardboard core for stability.
- The profile rolls are packaged on underlays to prevent soiling during installation.
- Always take profile rolls from the packaging together with the underlay.
- Store the cartons lying flat, not standing upright!!!
- Store and transport the cartons protected from uneven and high pressure.
- Max. stack height: 10 cartons.



4. Substrate preparation

- The substrate must be flat, dry, hard, firm and with no grease, dust and silicone.
- Cut wallpaper off 45 mm above the floor covering (DIN 18365).
- Level unevenness using a suitable filler, depending on the condition of the wall.
- The floor covering must be glued flat on the substrate at the edges.



5. Acclimatisation

Before installing, acclimatise the “WL 50 life” soft skirting board for 24 hours at minimum 16°C room temperature.

6. Installation method

Cutting

Use a Döllken skirting board shear or a carpet knife to cut to length.

Fastening

We recommend using the Uzin “Pomur 46” dry adhesive for the “WL 50 life” soft skirting board. This dry adhesive was specially developed for gluing down the “WL 50 life”. Note the Uzin AG Installation Instructions.

Application

- Place the profile on the floor on its buckled foot and press firmly against the wall.
- Ensure that the profile is pressed on without tensioning or stress.
- When gluing the “WL 50 life” soft skirting board with “Pomur 46”, the profile must be tapped on everywhere with a rubber mallet or rolled on with a wallpaper roller. This will ensure a more solid bonding between the “WL 50 life”, the dry adhesive and the wall.

DÖLKEN

W E I M A R

A SURTECO COMPANY



Forming corners

- To avoid creating stresses, the “WL 50 life” soft skirting board must be thoroughly pre-shaped at inside and outside corners.
- Use a rubber mallet for extra tapping of the pre-folded area against the wall.
- After prior bending, the profile is laid around the outside corner without cutting and without tensioning or stress.
- It is also possible to use a hot air blower to slightly heat the outside corner area after fastening the profile. This also allows any stress or stress whitening to be remedied.



- It is necessary at inside corners to cut the foot to prevent stress. To do this, cut the foot up to the bend position.

Zusammensetzung

- Position butt joints at inside corners, if possible.
- Butt joints may be welded using an axe-shaped welding tool.

Thank you very much www.doellken-weimar.de
Döllken Weimar GmbH, Profiles for the professional, quality assurance With the publication of this issue, all the previous ones lose their validity.

Stand: March 2015

DÖLLKEN

W E I M A R

A SURTECO COMPANY